



android

Premium next generation

Android OTT middleware and media receiver




FORMULER
www.formuler.tv

Installation **Step 1**

Connect your media receiver

Use an TV OUT cable to make the connection depicted in the diagram below:




- Connect one end to the TV OUT port on the back of your media receiver.
- Connect the other end to an open HDMI port on your TV.

Because TV OUT outputs digital video and audio, you don't need a separate audio cable.

Installation **Step 2**

Next, power on your media receiver by connecting it to a wall outlet using the included power adapter, like this:



Power on your TV and look for the Guided Setup on-screen.

If your TV does not display anything on-screen, make sure your TV input matches the physical connection used to connect your Media receiver. Press the Input button (sometimes called Source) on your TV or TV remote to cycle through the various video inputs available until you see the Guided Setup on-screen.

Installation **Step 3**

Configure your network


Step 3 establishes your network connection:

Wireless network

- Using the remote control, select your network from the list displayed on the screen. If your network is hidden, enter your network name.
- If required, enter your network password using the on-screen keyboard.

Wired network

- Connect one end of an Ethernet cable(not included) to your router. Connect the other end to the Ethernet port on the back of Media receiver.
- Media receiver will automatically detect your network and continue the set up process.



Troubleshooting

If you cannot see a picture on your TV:

- To match the STB system with your TV system (PAL/NTSC), press Resolution button until a picture is displayed.
- Check the video output port is firmly connected to the TV.
- Check that you have selected the Video Input on your TV.
- Check the brightness level of the TV.
- Check the resolution that your TV supports, and set the proper resolution with the remote Resolution button to obtain a picture.

No status light on the front panel:

- Check the main power cable and check that it is plugged into a suitable power outlet.


No Sound:

- See 'No Picture' above.
- Check the volume level of the TV and STB.
- Check the Mute status of the TV and STB.


Remote Control does not operate:

- Point remote control directly towards the STB.
- Check that the STB button lights up when you press any button.
- Check and replace batteries.

What's in the **box**?



Media Receiver




Remote control



2 x AAA batteries




Remote control extender




TV OUT Cable

Get to know your **Media receiver**

Front view





Back view



For optimal performance, place your receiver in an open cabinet or shelf.

Spec



www.formuler.tv

Get your **Air sync remote Z!**

Air Sync Wireless Remote and Multiscreen App

Use your Android phone to take control of your Formuler device with the Air Sync app. Control your set using your phone as a remote control. Stream your TV screen to the phone to watch from any room in the house. Download from the Google Play Store.



Android

Need more **help?**

www.formuler-support.tv

Get the most out of your FORMULER Set Top Box.

Check out our FAQs, instructional videos and user forums.



www.formuler.tv

FORMULER Z⁺

© 2017 by Formuler, Inc. All rights reserved. Formuler and the Formuler logo are registered trademarks of Formuler, Inc. Other brand and product names are trademarks or registered trademarks of their respective holders.